

METHOD AND APPARATUS FOR DETECTING AND MEASURING STATE OF  
FULLNESS IN CRYOPUMPS

ABSTRACT OF THE DISCLOSURE

The present system and method provides a mechanism for monitoring the level  
5 of fullness of a cryopump by measuring the cryopump adsorption capacity. An ion  
gauge or other total pressure gauge is in contact with the condensing or adsorbing panels  
of the pump. The gauge sensor, for example, can be connected to a tube or duct leading  
to the central core of the pump where the adsorbing charcoal is located. At this location  
in the pump, the gauge is exposed to low-boiling-point gases, such as hydrogen, neon  
10 and helium, while being substantially shielded from other gases such as nitrogen, argon,  
oxygen, or water vapor. By connecting a gauge to this location of the pump, the gauge  
can be used to monitor the absorption capacity of the pump.